



1. Bag with hardware



2. Take out the frame from the bag



3. Fix the connector with the foot



4. Twist the pole and fasten the foot



5. Put on the ground like this



6. Fix the top and bottom poles



7. Adjust the top and bottom poles



8. Put the top and bottom poles into the graphic



9. Fix the bottom pole with the left and right poles



10. Fix the top pole with the left and right poles



11. Adjust the graphic



12. Adjust the left and right poles